

In manual mode, turn the MPG override switch to a non- “OFF” state to enter the handwheel feed mode, Adjust the axis selection switch to select the corresponding feed axis, adjust the override switch to select the appropriate override, and then press the switch button on the left side of the handwheel, At the same time, shake the handwheel in the forward or reverse direction to realize the corresponding direction feeding.



notice:

- (1) The handwheel operation is only used for the small feed amount and the slow feed such as the tool setting operation, so the handwheel override value should be selected as a small value.
- (2) The handwheel has a magnet that can be attached to iron objects.

## Print Head Temperature Control Operation Interface


Press the "Print Head Temperature Control Interface" key to enter the print head real-time temperature control interface, It is mainly used for real-time monitoring of temperature changes and fine-tuning the extrusion volume of the print head.

- (1) In Mdi mode, there are two ways to warm up the print head :
  - a. The heating format is M200[A1,A2,A3,A4];  
As shown on the right, the heating command is M200[161,184,207,230]
  - b. The heating format is M104SA4, A4 is the value of the fourth group of heating coils, and the other three groups of heating coils are heated by the proportional value through the command M104, as shown in the right figure, the heating command is M104S230
- (2) A1~A4 on the left side of the interface, corresponding to 4 heating zones from heating zone A1 to heating zone A4;
- (3) The temperature on the left is the set temperature of the heating zone;
- (4) The temperature on the right is the actual temperature of the heating zone;
- (5)    The middle is the temperature percentage of the four heating zones, which can be adjusted according to actual needs through the "+" and "-" signs;
- (6)   The speed change ratio is the extrusion constant, and the extrusion amount can be manually adjusted according to "+" and "-" ;
- (7)  On-off switch for print head nozzles;
- (8)  Button to exit the real-time temperature control interface of the print head.




**Note:** When the nozzle (open), the screw extrusion can be carried out, otherwise, it will cause damage to the mechanical parts, Keep the air pressure at 0.6MPa. In addition, when the manual screw is extruded, avoid the left-hand wheel to prevent the internal screw from falling off.

rear part of the device







front part of the device





Click "Temperature Control Interface" to enter the interface. This interface is mainly used to start, adjust and close the temperature of the temperature console.

- (1) The temperature controller A1~A3 on the interface, the temperature controller B1~B3, correspond to the 6 heating zones of the temperature controller on the machine tool;
- (2) The temperature on the left is the set temperature of the temperature control console, and the maximum setting is 200°C;
- (3) The temperature on the right is the actual temperature of the thermostat;
- (4)  $100.0 \text{ } \left[ \begin{array}{c} - \\ 100\% \\ + \end{array} \right] 20.7$  The middle is the temperature percentage of the heating zone, which can be adjusted by the "+" and "-" signs according to actual needs;
- (6)  $\left[ \begin{array}{c} \text{EXIT/BACK} \\ \text{QUIT} \end{array} \right]$  Button to exit the real-time temperature control interface of the temperature control console.

1. Before starting the G code post-processing file, click  to pop up the workpiece program management menu;

2. Select the file to be enabled, and then click  to import the startup file. When the rate is determined to be 0, press the **start button**  to start running the G code, and adjust the feed rate  as required.

3. After selecting the specified file at the same time, click  to edit the internal code (as shown on the right)



UAO,1 is the origin coordinate system code; for other coordinate system codes, enter the document number to change the corresponding UAO code, the specific coordinate system parameters, and open the Table Editor coordinate origin interface to view.

```

N119 G601
N120 (UAO,1)
N121 (TCP,1)
N122 S4500 M03
N123 G00 G90 X15.0 Y14.0
N124 Z20.0
N125 ;
N126 X14.7 Y30.3 C0.0 A0.0
N127 Z15.0
N128 G01 Z-0.2 F700.0
N129 G03 X15.0 Y30.0 R0.3 F1000.0
N130 G01 X29.9718
N131 X30.2543 Y29.9837
N132 X30.3956 Y29.9605
N133 X30.5367 Y29.9266
N134 X30.8192 Y29.8245
N135 X31.1017 Y29.6692
N136 X31.3842 Y29.4436
N137 X31.4327 Y29.3955
N138 X31.6617 Y29.113
N139 X31.8194 Y28.8305
N140 X31.9234 Y28.548
N141 X31.9823 Y28.2656
    
```

# Table Editor Interface



The screenshot shows the OSAI Table Editor window. The main table displays the following data:

Table	ORIGIN			MEMORY			Measurement Unit		Process	Magazine	All
Origin	Axis X	Axis Y	Axis Z	Axis A	Axis C	Axis P	Axis W	Axis V	Description		
1	2206.93	958.319	-1157.57	-0.00000	-0.00000	0.00000	0.00000	0.00000			
2	1525.34	924.075	-1429.56	0.00000	0.00000	0.00000	0.00000	0.00000			
3	1498.60	1456.37	-1292.79	-0.00079	-0.00075	0.00000	0.00000	0.00000			
4	0.00000	0.00000	-1205.00	-0.00079	-0.00075	0.00000	0.00000	0.00000			
5	0.00000	0.00000	-1159.72	-0.00079	-0.00075	0.00000	0.00000	0.00000			
6	0.00000	0.00000	-1207.36	-0.00079	-0.00075	0.00000	0.00000	0.00000			
7	0.00000	0.00000	-1207.36	0.00000	0.00000	0.00000	0.00000	0.00000			
8	0.00000	0.00000	-1432.06	-0.00079	-0.00075	0.00000	0.00000	0.00000			
9	0.00000	0.00000	-1432.06	-0.00079	-0.00075	0.00000	0.00000	0.00000			
10	2528.87	850.957	-1286.60	-0.00079	-0.00075	0.00000	0.00000	0.00000			
11	1848.00	1041.00	-1286.60	-0.00000	-0.00000	0.00000	0.00000	0.00000			
12	1517.35	1469.97	-1286.60	0.00000	0.00000	0.00000	0.00000	0.00000			
13	0.00000	0.00000	-1207.04	0.00000	0.00000	0.00000	0.00000	0.00000			
14	0.00000	0.00000	-1204.21	0.00000	0.00000	0.00000	0.00000	0.00000			
15	0.00000	0.00000	-1238.43	0.00000	0.00000	0.00000	0.00000	0.00000			
16	0.00000	0.00000	-1206.10	0.00000	0.00000	0.00000	0.00000	0.00000			
17	0.00000	0.00000	-814.691	0.00000	0.00000	0.00000	0.00000	0.00000			
18	0.00000	0.00000	-814.691	-0.00079	-0.00075	0.00000	0.00000	0.00000		11	
19	0.00000	0.00000	-1206.17	-0.00079	-0.00075	0.00000	0.00000	0.00000			
20	1361.23	846.281	-1286.00	-0.00000	-0.00000	0.00000	0.00000	0.00000			
21	0.00000	0.00000	-0.00000	0.00000	0.00000	0.00000	0.00000	0.00000			
22	0.00000	0.00000	-0.00000	-0.00000	-0.00000	0.00000	0.00000	0.00000			

The detailed view below the table shows the following settings:

- Origin: 1
- Axis X: 2206.937665898
- Axis Y: 958.3199739139
- Axis Z: -1157.57
- Axis A: 0
- Axis C: 0
- Axis P: 0
- Axis W: 0
- Axis V: 0

Buttons: Apply, Cancel

1. Click  to enter the table editor, select  the menu, and set the origin of the workpiece coordinate position of the machine tool.
2. **Axis X**  Input the value corresponding to the index axis.
3. After entering the value, click Apply and close the interface.

# Table Editor Tool Number Interface





The screenshot shows the OSA Table Editor window. At the top, there is a menu bar with 'File', 'Select', 'Tables', 'Select Magazine', and 'Options'. Below the menu is a toolbar with various icons. The main area contains a table with columns for 'Table', 'OFFSET', 'Data Set', 'MEMORY', 'Measurement Unit', 'Process', and 'Magazine'. The table lists 21 rows of data with columns for 'Offset', 'Curr. Length 1', 'Length 1', 'Req. Length 1', 'Max Req. Len...', 'Curr. Length 2', 'Length 2', 'Req. Length 2', 'Max Req. Len...', 'Curr. Length 3', and 'Length 3'. Below the table is a configuration panel with various input fields and buttons.

Table	OFFSET	Data Set	MEMORY	Measurement Unit	Process	Magazine
1	0.00000			mm	1	All
2	391.50000					
3	391.50000					
4	403.50000					
5	193.63000					
6	391.40000					
7	158.83000					
8	172.59000					
9	170.95000					
10	177.06000					
11	273.89300					
12	247.43000					
13	0.00000					
14	0.00000					
15	188.22000					
16	191.86000					
17	225.44000					
18	431.53551					
19	0.00000					
20	275.29000					
21	275.34000					

Below the table is a configuration panel with the following fields:

- Offset 1:
- Length 1:  (with a spinner)
- Req. Length 1:  (with a spinner)
- Max Req. Length 1:  (with a spinner)
- Length 2:  (with a spinner)
- Req. Length 2:  (with a spinner)
- Max Req. Length 2:  (with a spinner)
- Length 3:  (with a spinner)
- Req. Length 3:  (with a spinner)
- Max Req. Length 3:  (with a spinner)
- Length 4:  (with a spinner)
- Req. Length 4:  (with a spinner)
- Max Req. Length 4:  (with a spinner)
- Length 5:  (with a spinner)
- Req. Length 5:  (with a spinner)
- Max Req. Length 5:  (with a spinner)
- Diameter 1:  (with a spinner)
- Req. Diameter 1:  (with a spinner)
- Max Req. Diameter 1:  (with a spinner)
- Diameter 2:  (with a spinner)
- Req. Diameter 2:  (with a spinner)
- Max Req. Diameter 2:  (with a spinner)
- Orientation:  (with a spinner)
- Real Variable 1:  (with a spinner)
- Real Variable 2:  (with a spinner)
- Real Variable 3:  (with a spinner)
- Real Variable 4:  (with a spinner)
- Real Variable 5:  (with a spinner)
- Real Variable 6:  (with a spinner)
- Real Variable 7:  (with a spinner)
- Real Variable 8:  (with a spinner)
- Real Variable 9:  (with a spinner)
- Real Variable 10:  (with a spinner)
- Int Variable 8:  (with a spinner)
- Int Variable 9:  (with a spinner)
- Int Variable 10:  (with a spinner)
- Description:

At the bottom of the configuration panel are two buttons: 'Apply' and 'Cancel'.

1. Click  to enter the table editor, select  the menu, and set the origin of the workpiece coordinate position of the machine tool.
2.  Input the value.
3. After entering the value, click Apply and close the interface.

## Mdi Mode Data Input Current Command Representation

1、 Start the print head heating:

By default, the M104S220 displays four heating temperature groups: 110, 165, 198, and 220, which can be re-adjusted within the system;

2、 Another input of the print head:

M104[110,165,198,220], if you need to change a group of temperature, you need to press the reset button, input the value of M104[A1, A2, A3, A4] corresponding to the heating zone, and then start it again;

3、 G602 Switch print axis;

4、 G601 Switch the cutting axis;


5、 (UAO,1) Coordinate position;

6、 (TCP,1) Represents the No. 1 center tool position compensation code.

In addition, after inputting an MDI command segment, press the "cycle start" button on the operation panel, and the system starts to run the input command.

## Five-axis head

名称		数值
Five-axis head	A-axis	$\pm 120^\circ$
	C-axis	$\pm 320^\circ$
spindle air pressure		0.6MPA
Spindle power		8.5KW
Spindle speed		24000
Spindle holder		HSK63F
use coolant		Antifreeze, water tank treasure, refrigeration fluid











Steps to replace the nozzle:

1. Before replacing the nozzle, it is necessary to remove the 4-M8 screw and remove the aerial rotating platform assembly. **Note that the motor wire is not allowed to be disconnected.**
2. After the rotating platform assembly is removed, the nozzle can be replaced (**higher length nozzle is required**).
3. In addition, the aerial rotating platform assembly is only suitable for the nozzle diameter of 5-8, and the other nozzle specifications do not require a rotating platform.



## 1. Mounting holes and outline dimensions

## 2. Technical parameter




### Technical parameter

Model	QG-025LS-ZBA-1225
Power system	1PH+PE220V/50HZ
Rated cooling capacity	2.5KW(water temperature 35°C, environment 35°C, water tank treasure)
Rated power/current	2.2KW/6A
Oil temperature settable range	5-55°C(It is recommended to use 20-40°C)
Oil temperature control accuracy	±0.5°C
Connection size	G1/2(1 for 1 time)
Refrigerant	R22
Use ambient temperature	10-43°C
Protection class	IP44
Noise	≤72dB(A)
Pump rated flow	2m <sup>3</sup> /h
Rated lift	37m
Colour	Ripple white
Applicable liquid	Water tank treasure, refrigerant

### 3. Protection function

The machine settings are: phase sequence protection, refrigeration high pressure protection, refrigeration low protection, oil temperature ultra-high protection, ambient temperature too high protection, oil pump overload protection, oil pump overload protection, compressor overload protection.


### 4. Power wiring



### 5. Signal wiring (no need to connect)


In the electrical control of the cooling machine, a passive alarm signal is provided for the machine tool host. When the cooling machine fails for some reason, the equipment down. The alarm terminals are completely independent contacts, and the maximum driving capacity is 220V3A. Two output modes of normally open point and normally closed point can be carried out inside the control, and the factory routine setting is normally closed point.

### 6. Working principle diagram of oil cooler



## 7. Electrical schematic

X1.GW531B.TY.F02M. Electrical Connection Diagram



### 1. Dehumidifying Dryer Connection Instructions

Use PVC steel wire hose to connect the raw material delivery pipe of the hopper.

Use PVC steel wire pipe to connect the negative pressure pipe of the hopper.


Connect the hopper signal wire.

Connect compressed air (0.6MPa).

### 2. Component Function Description Printing Extruder Feeding System

This machine adopts single barrel feeder:

- 1、 Three functions of drying, dehumidification and feeding.
- 2、 Maximum storage capacity: 75KG.
- 3、 Automatic feeding, automatic feeding.
- 4、 The amount of each feeding and the time of a single feeding can be set.
- 5、 The system is automatically controlled without human intervention.
- 6、 Maximum drying temperature: 150°C.
- 7、 Customized 160°C high temperature feeding tube.
- 8、 After the machine tool is turned off, press the heating button on the dehumidifying dryer panel to turn off, and wait for 5 to 10 minutes before turning off the device.



## 3.Engineering plastic drying temperature reference table (parameter setting)

Plastic name		Drying Temperature (°C)	Drying Time (h)
Chinese scientific name	General name		
丙稀腈-丁二烯-苯乙烯	ABS	80	3h
聚碳酸酯	PC	120	3h
聚碳酸酯-丙稀腈-丁二烯-苯乙烯	PC/ABS	100	3h
聚酰胺-6	PA6	80	3h
聚酰胺-66	PA66	80	3h
聚酰胺-66玻纤35%	PA66 GF35%	80	3h
聚甲基丙烯酸甲酯	PMMA	80	3h
聚甲醛	POM	100	3h
聚对苯二甲酸丁二醇酯	PBT	120	3h
聚苯醚/聚苯撑氧	PPO	100	3h
	PPE	100	3h
聚苯硫醚	PPS	150	3h
聚对苯二甲酸乙二醇酯	PET	125	3h

- 1) The standard of this machine is that the drying temperature is higher than 150 °C, and a special statement is required;
- 2) This machine is not suitable for sucking the raw materials with added toner;
- 3) **(Drying temperature)** Display the actual temperature value of the baking material of this machine;
- 4) The setting time of the suction control of the drying bucket indicates the amount of each time it enters the drying hopper;
- 5) The setting time of the material quantity control indicates how much each time it enters the injection hopper;
- 6) When there is no material level signal after feeding 5 times, it will prompt a material shortage alarm, press the **(Release alarm)** button to release the alarm;

## 4. Abnormal situation and handling reference

Phenomenon	Reason	Countermeasures
no action	No material shortage signal	Check the signal
	Action switch not turned on	Open the corresponding screen and turn on the switch
Suction motor running	The drying hopper can't pump the material	Solenoid valve not open
	Injection bucket can not draw material	The feed valve is not open
		The blanking time is set correctly
		Material shortage signal and screen switch, keep consistent
Drying hopper shortage alarm Injector I lack of material alarm Injector II material shortage alarm Injector III material shortage alarm	If the raw material has not been pumped after 5 times of pumping, stop the machine and give an alarm	Enter the corresponding computer screen, turn off the pumping, release the alarm, and turn it on again
Fan motor overload alarm	Current overload protection	After checking the cause, manually reset the overload protection and release the alarm
Suction motor overload alarm		
Temperature exceeds upper limit	Temperature over 180°C	abnormal heating
	The temperature exceeds the fixed value by 20°C	Adjust the set value
Can't heat up to set value	Hot air motor reverse	Swap the power cord
	The heating tube is broken	replace
	Heating Magnetic Destruction	replace
No display on boot	Out of phase	Check the power cord
	Blown fuse	Check the reason for well replacement
	Switching Power Line Indicators	Replacing the DC 24V fuse
	Switching power supply without indicator light	Replacing the AC 220V fuse
Alarm after power on	Special note: The current of the fuse used in this machine is 1 A, please do not increase the current, otherwise it will not be able to play a protective role, which may cause unforeseen failures.	
	reverse phase protection	