



 User Manual

ANYCUBIC PHOTON M3

Dear customer,

Thank you for choosing **ANYCUBIC** products.

Maybe you are familiar with 3D printing technology or have purchased **ANYCUBIC** printers before, we still highly recommend that you read this manual carefully. The installation techniques and precautions in this manual can help you avoid any unnecessary damage or frustration.

Please visit <https://www.anycubic.com/pages/contact-us> to contact us if you have any question. You can also gain more information such as software, videos, models from the website.



ANYCUBIC support center

Team **ANYCUBIC**

Copyrighted by "Shenzhen Anycubic Technology Co., Ltd ", all rights reserved.

Safety Instructions

Always follow the safety instructions during assembly and usage, to avoid unnecessary damage to the 3D printer or individual injury



Please contact our customer service first if you have any issue after receiving the products.



Be cautious when using the scraper. Never direct the scraper towards your hands.



In case of emergency, please immediately cut off the power of **ANYCUBIC** 3D printer and contact the technical support.



ANYCUBIC 3D printer includes moving parts that can cause injury.



It is recommended to use protection glasses when sanding the printed models to avoid eye contact with small particles.



Keep the **ANYCUBIC** 3D printer and its accessories out of the reach of children.



Vapors or fumes may be irritating at operating temperature. Always use the **ANYCUBIC** 3D printer in an open and well ventilated area.



ANYCUBIC 3D printer must not be exposed to water or rain.



Operate **ANYCUBIC** 3D printer with a temperature of 8°C-35°C and a humidity of 20%-50%. For optimal performance, do not exceed this range. Also, avoid direct sunlight exposure.



Do not disassemble **ANYCUBIC** 3D printer, please contact technical support if you have any question.

Contents

1. Technical Specification	5
2. Packing List	7
3. Product Overview	8
4. Menu Directory.....	9
5. Assembly and Leveling Instructions	12
6. First Print Instructions	16
7. Slicing Software Overview	19
8. FAQ and Machine Maintenance	20

Technical Specification

Printing

System	Anycubic Photon M3
Operation	2.8-inch Color TFT Screen
Software	Anycubic Photon Workshop
Connectivity	USB memory stick

Specifications

Technique	LCD Shadow Masking
Light source	UV-LED (wavelength 405nm)
XY Resolution	4096*2560 (4K)
Z axis Accuracy	0.01 mm
Suggested Layer Thickness	0.01-0.15 mm
Print Speed	Max 50 mm/h
Rated power	55 W

Physical Dimensions

Dimension	269 mm (L)* 256 mm (W)* 425 mm (H)
Build volume	163 mm (L)* 102 mm (W)* 180 mm (H)
Materials	405nm UV-resin
Net weight	~7 kg

Technical Specification

Recommended Printing Parameters














Layer Thickness	0.05 mm
UV power	100%
Normal Exposure Time	2 s (for the transparent color resin, it is 1.5~2 s; for others, such as grey, black, white and skin color resin, it is 2~3 s)
Off Time	0.5 s
Bottom Exposure Time	23 s
Bottom Layers	4
Z Lift Distance	6 mm
Z Lift Speed	3 mm/s
Z Retract Speed	4 mm/s
Anti-alias	1

Note:



- 1.The recommended printing parameters above is for reference only, which is more suitable for Anycubic resin.
2. The UV power of the machine is high. If there are solid residue in the resin vat or on the printing platform frequently, please decrease the UV power and increase the normal exposure time.
3. Please add off time (reference range: 0.5~3s) if you use the resin with poor flow ability or print model with complex structure.



Packing List

			
	Print platform 1PC	Resin vat 1PC	
			
Anycubic Photon M3	USB memory 1PC	Scrapers 2PCS	
			
Mask 1PC	Gloves 3Pairs	Funnel 5PCS	Assembly Instruction 1PC
			
Leveling paper 1PC	Screen protector kit	Tool kit	Power adaptor

Product Overview




Menu Directory

Home menu



Print




System



Tools



Home menu



Enter Print Menu


Enter System Menu

Enter Tools Menu

Menu Directory

Print

File List:




Click Files




System

Language: Change language(English/Chinese)

Service:



Information:



Menu Directory

Tools

Move Z:



Move Z by 0.1mm/1mm/10mm

Move the Z axis upwards


Return to Zero

Stop moving the Z axis

Return to Tools Menu

Move the Z axis downwards

Detection:



Select one of the images to detect

Click to set the test time


Reduce the test time

Test LED and DMD for the preset time

Return to Tools Menu

Increase the test time

Gear icon:



Click to set UV power

Return to Tools Menu

Z=0: Reset the zero point

Horn icon: Turn on/off the screen sound

Assembly and Leveling Instructions

1. Unpack the machine and take out the accessories. Then plug in the power cord and turn on the printer.



2. Rise the Z axis to a certain height to ensure that the curing screen will not be scratched when printing platform is installed.




3. Tear off the protective film before leveling and printing.






Assembly and Leveling Instructions


4. Loosen the four screws on the printing platform.



5. Install the printing platform.



6. Place a leveling paper on the curing screen. Then click “” on the touch screen. Wait for the Z axis to descend and stop automatically.



Assembly and Leveling Instructions

7. Use your fingers to press the platform gently, to let it fit evenly on the curing screen. Then tighten the four screws on the platform.





8. Click "Tools" → "Z=0" on the touch screen, and then click "Enter" on the pop-up window. Till now, the leveling process is finished. Click "Enter" again on the pop-up window and pull out the paper.



9. Testing UV light: Raise printing platform until the curing screen can be observed completely. Click "Tools" → "Detection", select a image, set the test time and then click "Next". It should display a complete image as what you select.

Assembly and Leveling Instructions



the result of first image

10. Install the resin vat.




First Print Instructions

1. Print


***Please check FEP film carefully before and after every printing. If the FEP film is broken, replace it immediately to avoid further damage to machine.**

Insert the USB memory (the test file "TEST.pm3" has been saved in it) into the USB port. **Then wear masks and gloves (to avoid direct skin contact with resin)**, slowly pour the resin into the vat and the resin cannot exceed the vat's maximum scale.

After that, put on the cover. Take off the gloves, select the "TEST.pm3" test file and start printing. (The printing time on the screen is for reference only, we make no guarantee that it is the actual printing time.)



Do not exceed the maximum scale on the vat




If you think the resin is insufficient to finish an ongoing print (or you want to change the resin), you can click "Pause", the platform will rise, and you can slowly add (or change) the resin. After that, click "Start" to resume.

First Print Instructions



click to pause





click to start


2. Set UV power

There are two ways to set UV power.

Before printing, click "Tools"→"  ". Then click "UV power" in the setup interface to set UV power.



Besides, in the process of printing, click "  " in Print interface, page down to find "UV power". Then click it to set UV power.



First Print Instructions

3. Handling models and residues

After printing, unscrew and remove the platform when resin stop dropping from the platform. The model can be removed by scrapper carefully. The removed model should be washed with ethanol 95vol% concentration. The printed object may need post curing to achieve better hardness by direct **sunlight** or UV-curing box.



【IMPORTANT】 Inevitably, in case of incomplete curing or failed prints, there might be some cured resin left in the vat. It is suggested to filter the resin by a funnel and then store the liquid in a sealed container. The residues left on the platform or in the vat can be wiped off with paper towel.

Before each prints, please ensure there is no solid residues in the vat or on the platform, otherwise the FEP film may be crushed and broken during printing.

Slicing Software Overview

3D printer reads sliced file and prints models. It is necessary to convert 3D files (stl./obj.) into sliced files for machine to recognize. Software that realize the process is called slicing software, for example, Anycubic Photon Workshop.

Anycubic Photon Workshop can be used to export sliced file. You should select **Anycubic Photon M3** as machine type first, then manipulate the model and set the parameters. Lastly, export the sliced file (.pm3).

The instruction of Anycubic Photon Workshop has been saved in the USB memory, it is recommended that read it carefully if it is the first time for you to use Anycubic Photon Workshop.

FAQ and Machine Maintenance

1. FAQ

(1) Model do not stick to platform

- Bottom exposure time is insufficient, increase the exposure time.
- Contact area between the model and platform is small, please add raft.
- Bad leveling.

(2) Layer separation or splitting

- The machine is not stable during printing.
- FEP film in the vat is not tight enough or it need a change for new one.
- The printing platform or resin vat is not tightened.
- Add normal exposure time appropriately.
- Add off time appropriately.
- The lift speed is too fast.
- The printing object is hollowed without punching.

(3) Layer shift

- Add supports.
- Reduce the lift speed.

(4) Floccules left in resin vat

- The exposure time is too long. Reduce the normal exposure time and bottom exposure time.

2. Machine maintenance



- (1) If Z axis make noisy sound, please apply lubricant to Z lead screw.


FAQ and Machine Maintenance



(2) Clean off the residues cured on FEP film when the printing fail: Set full-screen exposure for 20s and then remove the cured resin sheet to protect the film. **Do not use sharp objects to scrape off the residues on FEP film.**



(3) Be careful when remove the platform, do not let it fall to damage the machine.



(4) Do not left resin in resin vat for over two days when it is unused. Please filter and store the resin properly.

FAQ and Machine Maintenance

(5) After printing, please clean up the platform (**wipe with paper towels or wash with alcohol**), and ensure no residue left (**filter the residue with funnel**).

(6) If the body of printer is stained with resin, use alcohol to clean.

(7) Please clean the resin vat first before you change resin.

Thank you for purchasing **ANYCUBIC** products! Under normal usage and service, the products have a warranty period up to one year. Please visit **ANYCUBIC** support center(support.anycubic.com/en) to report any issue with **ANYCUBIC** products. Our professional after-sale service team would respond within 24 hours and solve the issues.